
Meridian Administration Tools

MAT Quick Installation Guide

Document Number: P0871738

Document Release: Standard 5.7

Date: October 1997

© 1994, 1996, 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Document Revision history

Date	Document Version	Product Release
October 1997	Standard	MAT 5.7
July 1997	Preliminary	MAT 5.7
May 1997	Standard	MAT 5.6

Contents

About MAT Quick Installation Guide	1
Who should use this guide	1
What this guide contains	2
Conventions used in this guide	2
 Preparing for MAT 5 Installation	 3
Step 1: Check PC Hardware and Software	3
Step 2: Set Up Windows 95 Networking for MAT	4
Step 3: Set Up the Communications Environment	6
Step 4: Set Up the Meridian 1 for Ethernet and PPP	7
Step 5: Set Up a Network Environment	8
Step 6: Set Up the Server Environment	9
 Installing the MAT 5 Software	 11
Installing MAT 5 on a Stand-alone PC	12
Installing MAT 5 on the Server and First Client PC	14
Installing MAT on Additional Client PCs	17
Converting Data to MAT 5 Format	19
 Validating the MAT Installation	 21
Step 1: Login and change default password	21
Step 2: Set Up Communications Information	22
Step 3: Set Up Customer Information	22
Step 4: Set Up MAT Applications	22
Step 5: Set Up System Data Information	23
Step 6: Connect to the System	23

Upgrading from an Earlier Version of MAT 5 25

**Adding Applications or Licenses to
a Stand-alone PC 27**

**Adding Applications or Licenses to
Client PCs 29**

Step 1: Add Applications or Licenses to First Client PC 29

Step 2: Add Applications or Licenses to Other Client PCs 29